

OWNER'S MANUAL

Dehumidifier

Model: GDN20AX-K4EBA1A、GDN20AX-K4EBA1B

Thank you for choosing our product.

For proper operation, please read and keep this manual carefully. If you have lost the Owner's Manual, please contact the local agent or visit www.gree.com or sent email to global@gree.com.cn for electronic version.

Content

Operation Notices

 Safety Precautions Operation Area Parts Name Check Before Operation 	2 3
Operation Instructions	
Operation Method Drainage Method	5 8
Maintenance	
Clean and Maintenance	11
Malfunction	
Troubleshooting. Error Codes	13

Note:


Graphics in this manual are only for reference. Please refer to actual products for specific details.

Safety Precautions

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory ormental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Before operation, please check the power cord if it complies with the requirement indicated on the nameplate.
- Before cleaning, please turn it off and unplug the dehumidifier.
- Make sure the power cord is not pressed by any hard objects.
- Do not remove the power plug or move unit by pulling the power cord.
- Do not operate any heating appliances near the dehumidifier.
- Do not move get the power plug with wet hands.
- Please use grounded power cord and make sure it's well connected and not damaged.
- Children and disabled people are not allowed to use the dehumidifier without supervision.
- Keep children from playing or climbing on the dehumidifier.
- Memory function is included in this dehumidifier. When nobody is taking care of the unit, please turn it off and remove the power plug or disconnect power.
- Do not repair or disassemble the unit by yourself.
- Damaged power cord must be replaced by qualified technicians or manufacturer.
- If abnormal condition occurs (e.g. burned smell), please disconnect power at once and then contact local dealer.
- Dehumidifier can not be disposed of everywhere. If you want to get rid of this dehumidifier, please check with local handling disposal or information service center about what to do.
- Do not use an extension cord.

Operation Area

- This dehumidifier is intended for indoor applications only. It should not be used for commercial or industrial applications.
- Place the dehumidifier on a smooth and level floor.
- During operation, the nearby enclosed space, such as wardrobe can't be dehumidified.
- Place the dehumidifier in an area where the temperature will not below 5°C or above 35°C.
- During operation, please make sure there's enough space around the unit.
- Close all doors, windows and other outside openings of the room to improve the working effect.
- Please keep the air inlet/outlet clean and not blocked.
- Avoid direct sunlight.




Note:


- The dehumidifier has rollers to aid placement. Do not attempt to roll the dehumidifier on carpet or over objects. Otherwise, water may spill out from the bucket or the dehumidifier may get stuck by the objects.
- Please stop operation before moving the dehumidifier. The tilting angle can't be too large when moving the unit. Do not move the unit along front or back direction.

Parts Name

Front Side



Back Side




Check Before Operation

Before operation, please first check whether float is properly placed. Below are the checking steps:


1. Hold the handles on both sides of the water bucket and pull it out following the arrow direction.



2. Check whether float in the water bucket is properly placed. It might have been moved a little after long-time transportation. If it's not placed properly, move it to the correct position by hand.








Wrong Position

3. Replace the bucket as instructed in step 1.

Operation Method



Notes:

- Water bucker must be correctly installed for operation.
- Do not remove the bucket while unit is in operation.
- If you want to use drain hose to drain water away, please install the hose according to section "Drainage method".

Basic Functions of the Buttons

- ON/OFF Button
 Press this button to turn on/off dehumidifier.
- 2 Timer Button Press Timer button to set timer on or timer off. The timer can be set in 1h increment among 0-24h with each press of Timer button. If hold the Timer button, time will increase rapidly circularly. After timer is set, time will be displayed for 5s and timer indicator will be on.

3 Humidity Button

Press Humidity button to set your required humidity. If hold Humidity button, humidity can be set in 10% increment among 30%-80% circularly. After that, the set humidity will be displayed for 5s.

4 Mode Button

Press Mode button can set 4 kinds of dehumidify mode - Smart, Cont., Quiet and Dry.

- If smart indicator is on, it indicates the unit enters into smart mode. The
 unit will intelligently select the comfortable humidity for human according
 to current temperature.
- If cont indicator is on, it indicates the unit enter into continuous dehumidify mode. The unit will always dehumidify only until the humidity is decreased to the inapplicable humidity of human.
- If the quiet indicator is on, the unit enter into quiet mode. The unit will
 intelligently select the comfortable humidity for human according to current
 temperature. The unit will operate at the fan speed whose noise is the
 lowest. The fan speed can't be adjusted.
- If the dry indicator is on, the unit enters into dry mode. After clothes are dried, room humidity will be kept at certain range to prevent mildew. Under dry mode, fan speed and humidity can't be adjusted.

Note:

- Under smart mode and quiet mode, if room humidity is lower than set humidity, or lower than the defaulted comfortable temperature, the unit will stop dehumidifying.
- Under dry mode and cont mode, the humidity can't be adjusted. Under dry mode and quiet mode, fan speed can't be adjusted.

5 Fan Button

Press Fan button can set high, medium or low fan speed. When the corresponding indicator is on, it indicates the current fan speed has been set.

Other Instructions

1. Auto Stop

When bucket is full, remove the unit or not placed the unit correctly or the humidity is 5% lower than the set humidity, the unit will stop operation automatically.

2. Memory Function

If power failure, all settings will be memorized. After power recovery, the unit will resume operate according to the memorized settings.

3. Bucket full light

This indicates that bucket is full or removed or not placed correctly.

4. Filter reset

When the indicator of filter clean is on, it needs to clean filter. After filter is cleaned, press Fan button and Humidity button simultaneously and then the indicator of filter clean will be off.

5. Child lock function

Press Mode button and Timer button simultaneously for 1s to enter into child lock protection. After pressing any button, LC will be displayed to indicate buttons are locked. Press Mode button and Timer button simultaneously for 1s again to release shielding function.

Drainage Method


Method 1: Drain water through water bucket

Notes:

- Do not remove the bucket when unit is in operation or has just stopped. Otherwise it may cause some water to drip on the floor.
- Do not use the hose if using water bucket to collect water. When the hose is connected, water will be drained out through it instead of into the bucket.
- 1. Hold the handles on both sides of the water bucket and pull it out following the arrow direction. (Attention: Pull out the bucket carefully in case the water may spill out from the bucket and onto the floor.)



2. Pour out the water.




3. Replace bucket in the dehumidifier according to the arrow direction.



Method 2: Drain water through drain hose

This unit is connect with drain outlet. User can purchase the drain hose whose inner diameter is 14mm (length is 1.3-1.5m) and assemble it on the drain adapter to drain condensate water. When assembling the continuous drain equipment, do turn off the unit and pull out the power plug.

 Open continuous drain outlet and then remove the drain cover along the arrow direction as shown in below arrow.



Note:


When using the water bucket to drain water, please re-assemble the drain cover and the drainage choke plug. Otherwise, leakage may occur when using water bucket to drain water.

2. Remove the drainage choke plug at first, rotate the drainage adapter into the continuos drain outlet in clockwise direction.

Pull the drainage adapter through the continuous drain outlet, and then rotate it into the drain outlet of the unit tightly. Please check whether the gasket is in good condition.

Note:


After removing the drainage choke plug, there will be a little residual condensate water. Please use container to collecting it to prevent moistening the floor.



3. Insert the drain hose into drainage adapter to make sure the water won't leak out. The horizontal height of drain hose should not be higher than the drain outlet. Do not block the drain outlet to make the condensate water can be drained out smoothly. Please check drainage adapter and drain hose periodically to see whether they are connected tightly and whether they are damaged or blocked.

Note:

Please make sure the drain hose is put along the direction of drain out of water bucket. Insert one end of drain hose into the floor drain and then cover the lid of floor drain. Please do not press and flatten the drain hose.



Clean and Maintenance

Warning:

- Before cleaning, turn off the dehmidifier and disconnect the power.
 Otherwise, it may lead to electric shock.
- Do not wash the dehumidifier with water, or it may lead to electric shock.
- Do not use volatile liquid(such as thinner or gasoline) to clean dehumidifier.
 Otherwise it will damage unit's appearance.

1. Grille and Case

To clean the case:


When there is dust on the case, use soft towel to dust it off; When the case is very dirty(greasy), use mild detergent to clean it.


To clean the grille: Use a dust catcher or brush.

2. Water Bucket

Every few weeks, clean the bucket to prevent growth of mold, mildew and bacteria. Use soft brush to clean the bucket and then rinse it.

- 1. Take out the water bucket and then pour out the residual water.
- 2. Press down 4 buckles around the water bucket. Lift up the drain lid.





3. After cleaning, replace the drain lid and make sure the float of water bucket is placed properly. The side with foam plastic should be beneath the drain lid. Do not remove the foam plastic on the float.


3. Air Filter

1. Remove panel

Open the clasps at both sides of lower side of panel, open the panel as shown in fig 1, and open it to 20° . Do not open it forcibly or open the angle too large. As shown in fig 2, pull up the panel to remove it.

2. Remove air filter

As shown in fig ③, pull the clasps of air filter outwards to remove the air filter.




3. Clean air filter

Use dust catcher to absorb dust on the surface of air filter. If the air filter is very dirty, clean it with warm water melted with neutral detergent and then dry it completely.

4. Install air filter

Insert the clasp at lower part of air filter into the unit and then press the air filter downwards until you have heard a sound. After that, re-assemble the panel.



Warning:

- Do not operate the dehumidifier without a filter.
 Otherwise the evaporator will catch dust and affect unit's performance.
- Do not dry the air filter with fire or electric hair dryer. Otherwise the air filter may be unshaped or caught on fire.
- Don't use dust catcher or brush to clean the air filter. Otherwise the air filter may be destroyed

Check Before Use-season

- Check whether air outlet is blocked.
- Check whether power plug and power socket are in good condition.
- Check whether air filter is clean.
- Check whether drain hose is damaged.

Care After Use-season

- Disconnect power.
- Clean air filter and case.
- Clean dust and obstacle of the dehumidifier.
- Empty the water bucket.

Long-time Storage

If you won't use the dehumidifier for a long time, we suggest that you follow the steps below in order to maintain the unit in good condition.

- Make sure the water inside the water bucket is poured out and then drain hose is removed.
- Unplug the dehumidifier and pack the power cord.
- Clean the unit and then wrap it well for preventing dust.

Troubleshooting

• Not all the following problems are malfunctions.

Problem	Possible Causes
Dehumidifier is not operating. Controls can not be set.	 Unit is operating in an area where temperature is higher than 35°C or lower than 5°C. Bucket is full.
Noise suddenly rises during operation.	 Noise will rise if compressor has just started. Power supply problem. Unit is placed on uneven floor.
Humidity does not drop.	 Area to be dehumidified is too large. The capacity of your dehumidifier may not be adequate. Doors are open. There might be some device producing vapor in the room.
Little or no effect in dehumidifyng	 Room temperature is too low. Humidity level may be improperly set. If unit is operating in a room where temperature is from 5 to 15 °C, it will start to defrost automatically. Compressor will stop for a brief period of time(fan will operate in high fan speed). When unit finishes defrosting, it will be back to normal operation.
When first operated, the air emitted has musty-odor.	 Due to temperature rising of heat exchanger, the air may have some strange smell at the beginning.
Unit has noises.	 There might be some noise if unit is operating on wooden floor.
Swooshing sound is heard.	Normal. This is the sound of the flow of refrigerant.

• Problem of water leakage

Problem	Possible Causes	Solution
When using drain hose, there is water in the bucket	• Examine the drainage joint.	 Connect the drainage joint well.
		 Clear the obstacle from the drain hose.
	Drain hose is not correctly installed.	 Remove the drain hose and replace it. Be sure that the hose is correctly installed.

• Dehumidifier can't be started up.

Problem	Possible Causes	Solution	
Power indicator is not lit when power is connected.	the dehumidifier or the	 Check if power is lost. If yes, wait for the power to restore. If not, check whether the power circuit or power socket has been damaged. Check whether power plug is loosen. Check whether power cord is damaged. 	
	Fuse is blown.	Replace the fuse.	
Bucket full indicator is lit up.	 Bucket is not properly placed. Water is full in the bucket. Bucket has been removed. 	 Empty the bucket and replace it. 	
Unit can function normally but it can not start up.	Humidity is set too high.	 If you want the air drier, press - button to lower the figure or press CO button for unit to dehumidify continuously. 	

• Dehumidifier does not dry air as intended.

	 Check whether there is any obstacle around the unit. 	 Make sure there is no curtain, shutter or furniture that blocks the dehumidifier.
	 Air filter is dusty and blocked. 	Clean the filter.
	Doors and windows are left open.	 Make sure all doors and windows and other opening to the outside have been closed.
	Room temperature is too low.	 Warm temperature is good for dehumidification. Low temper- ature will reduce unit's working effect. This unit should be wor- king in a place where temper- ature is above 5°C.

Error Codes

Unit's Malfunction Codes

N	Malfunction	Display Code	Unit's Condition	Describle Course	
No.	Name	Display Window		Possible Causes	
	Ambient Temperature Sensor Malfunction	F1		 Ambient temperature sensor is loosen or is poorly connected with the terminal of display board. 	
1				 Some element of display board may have been put upside down and cause short circuit. 	
				 Ambient temperature sensor is damaged(Please refer to Chec- king Table for Temperature Sen- sor Resistance). 	
				Compressor and fan	and fan
	Tube Temperature Sensor Malfunction				
2		F2		Some element of display board may have been put upside down and cause short circuit.	
Ivialiunction				 Temperature sensor on the eva- porator is damaged(Please refer to Checking Table for Temperature Sensor Resistance). 	
				Display board is damaged.	
3	Humidity Sensor Malfunction	L1		Humidity sensor is short-circuited.Humidity sensor is damaged.Display board is damaged.	

Na	Malfunction Name	Display Code Unit'	Unit's Condition	Possible Causes
No.		Display Window		Possible Causes
4	Freon-lacking protection	F0	The compressor stops; the fan motor keeps on running.	Refrigerant is leaking.System is blocked.
5	Overload protection	НЗ		 Ambient operation condition is bad. The evaporator and condenser are blocked with filth. The system is abnormal.